


Medical Image Processing for Diagnostic Applications

3-D Data – Plane-Integrals

Online Course – Unit 45

Andreas Maier, Joachim Hornegger, Markus Kowarschik, Frank Schebesch

Pattern Recognition Lab (CS 5)



Topics

Parallel Plane-Integral Data

3-D Radon Transform

Central Slice Theorem

Backprojection

Summary

Take Home Messages

Further Readings

3-D Radon Transform

The 3-D Radon transform is not equal to the X-ray transform!




Figure 1: Integral over a plane through the object $f(x, y, z)$ at distance s from the origin and normal θ (Zeng, 2009)

3-D Radon transform

- We do not have direct detectors for this transform.
- We can compute the value of such a “detector” as a line-integral on a 2-D parallel beam detector.
- There is a central slice theorem for this transform.
- Backprojection is different as a point has to be backprojected as a plane into 3-D.




Figure 2: Scheme of the Radon transform (Zeng, 2009)

Central Slice Theorem for Plane-Integral Data




Figure 3: This central slice theorem connects the 3-D Fourier transform of the object with the 1-D Fourier transform of the plane-integrals (Zeng, 2009).

Parallel Plane-Integral Data: Backprojection




Figure 4: Scheme of how the plane-integral data can be backprojected (Zeng, 2009)

3-D Radon Inversion Formula

$$f(x, y, z) = -\frac{1}{8\pi^2} \iint_{[0, 2\pi]^2} \frac{\partial^2 p(s, \boldsymbol{\theta})}{\partial s^2} \Big|_{s=\mathbf{x} \cdot \boldsymbol{\theta}} \sin \theta \, d\theta \, d\phi,$$

where

$$\boldsymbol{\theta} = \begin{pmatrix} \sin \theta \cos \phi \\ \sin \theta \sin \phi \\ \cos \theta \end{pmatrix}$$




Figure 5: Diagram shows the different angles and other variables of the inversion formula (Zeng, 2009)

Topics

Parallel Plane-Integral Data

3-D Radon Transform

Central Slice Theorem

Backprojection

Summary

Take Home Messages

Further Readings

Take Home Messages

- There is a central slice theorem for parallel plane-integral data in 3-D.
- The 3-D Radon transform cannot be directly translated into detector hardware, but it can be inverted and therefore be considered for reconstruction algorithms.

Further Readings

The best way to augment your knowledge of the shown concepts is to read the companion book of the current chapter:

Gengsheng Lawrence Zeng. *Medical Image Reconstruction – A Conceptual Tutorial*. Springer-Verlag Berlin Heidelberg, 2010. DOI: [10.1007/978-3-642-05368-9](https://doi.org/10.1007/978-3-642-05368-9)